Bidbury & C?

HOW TO REFIT THE CHARLBURY HANDLE

INSTALLATION INSTRUCTIONS

INSTRUCTIONS

(p) -

PLEASE READ THESE INSTRUCTIONS CAREFULLY AND KEEP IN A SAFE PLACE FOR FUTURE REFERENCE.

This will require two people to complete

ENSURE COLD SUPPLY IS TURNED OFF BEFORE REMOVING ANY PARTS.



Isolate water supply before starting.



Take care to keep upright to ensure inner fitting do not fall out.



Whilst holding in position, line up the lever and place the pin through both holes.



Unscrew and remove the spray cover and rubber seal.



Using the end of a wooden spoon or similar, push the inner mechanism towards the lever.



Release the internal mechanism to return back to original position.



Remove inner brass ring.



The pin and lever can be removed to reveal the internal shaft.



Re-fit all other parts in reverse order. **NOTE:** do not over tighten the spray cover – doing this will take pressure off the pin and cause it to fall out.